

Winlink INI-Kommandos an Kenwood Funkgeräte

Bei der Arbeit mit Winlink hatte ich mir mal die Kommandos angeschaut welche das Programm beim Start an ein Funkgerät schickt. Vielleicht kann es jemand mal gebrauchen - wozu auch immer ...

Zuerst wird zum verlassen aller eventuellen Modis folgender String geschickt (hex!) :

```
C0 FF C0 0A 03 03 03 C0 FF C0 0D 0D
```

Danach kommt in ASCII jeweils die Parametrierung für Band und Geschwindigkeit. Jede Zeile wird nur mit \$0D abgeschlossen.

```
### TH-D7 A-Band 1200
```

```
TC 1
TNC 2
BC 0
DTB 0
TC 0
```

```
MONITOR OFF
HBAUD 1200
KISS ON
RESTART
```

```
### TH-D7 A-Band 9600
```

```
TC 1
TNC 2
BC 0
DTB 0
TC 0
```

```
MONITOR OFF
HBAUD 9600
KISS ON
RESTART
```

```
### TH-D7 B-Band 1200
```

```
TC 1
TNC 2
BC 1
DTB 1
TC 0
```

```
MONITOR OFF
```

HBAUD 1200
KISS ON
RESTART

TH-D7 B-Band 9600

TC 1
TNC 2
BC 1
DTB 1
TC 0

MONITOR OFF
HBAUD 9600
KISS ON
RESTART

TM-D700 A-Band 1200

TC 1
TNC 2
BC 0,0
DTB 0
TC 0

MONITOR OFF
HBAUD 1200
KISS ON
RESTART

TM-D700 A-Band 9600

TC 1
TNC 2
BC 0,0
DTB 0
TC 0

MONITOR OFF

From:
<https://www.elektronikfriedhof.de/> - **dg1sfj.de**

Permanent link:
<https://www.elektronikfriedhof.de/doku.php?id=funk:funkmisc:winlink>

Last update: **2025/01/18 11:47**

